



15301914
Revision C
February 2025

Lubricator Assembly

2000 Series


Parts Information



Save These Instructions

ARO

Lubricator Assembly 2000 Series L363X1-XXX Exploded Diagram




(Dwg. 15318678)

Lubricator Assembly 2000 Series L363X1-XXX Parts List

Item	Part Description	Material	Part Number	Item	Part Description	Material	Part Number
1	Lubricator Body	Aluminum	---	12	Spring	Stainless Steel	---
	3/8" BSP (L363C1-XXX)			13	Bolt	Steel	---
	1/2" BSP (L363D1-XXX)			14	Siphon Tube	Urethane	---
	3/4" BSP (L363E1-XXX)			15	Sight Dome Housing	Nylon	---
	3/8" NPT (L36331-XXX)			16	Outer Sight Dome		---
	1/2" NPT (L36341-XXX)			17	Outer Sight Dome O-Ring	Nitrile	---
	3/4" NPT (L36351-XXX)			18	Inner Sight Dome O-Ring		---
2	Upper Cover (L)	Nylon	---	19	Inner Sight Dome	Nylon	---
3	Poly Bowl (See Page 3)	---	---	20	Nozzle Sheet	Nitrile	---
	(L363X1-100)			21	Fill Cap O-Ring		---
4	Damper	Nitrile	---	22	Fill Cap	Acetal	---
5	Damper Guide Gasket		---	Lubricator Repair Kit (Includes Items 4, 5, 6, 7, 8, 15, 16, 17, 19, 21, 22, and Bowl O-Ring)			
6	Steel Ball (Small)	Steel	---	(L363X1-XXX)			
7	Check Ball O-Ring	Nitrile	---	Sight Dome Repair Kit (Includes Items 15, 16, 17, 19)			
8	Damper Guide	Acetal	---	(L363X1-XXX)			
9	Steel Ball (Large)	Steel	---				
10	C-Bracket		104409				
11	Metal Bowl (See Page 4)	---					
	(L363X1-110, L363X1-120)						

Poly Bowl Assembly 2000 Series Exploded Diagram




(Dwg. 15318702)

Poly Bowl Assembly 2000 Series Parts List

Item	Part Description	Material	Part Number	Item	Part Description	Material	Part Number
1	Lock Button (L363X1-100)	Nylon	---	4	Bowl Guard (L363X1-100)	Nylon	---
2	Poly Bowl (Includes Items 1, 3, 4 & 5) (L363X1-100)	Polycarbonate	104336	5	Lock Button Spring (L363X1-100)	Stainless Steel	---
3	Bowl O-Ring (L363X1-100)	Nitrile	---				

Metal Bowl Assembly 2000 Series Exploded Diagram



(Dwg. 15318710)

Metal Bowl Assembly 2000 Series Parts List

Item	Part Description	Material	Part Number	Item	Part Description	Material	Part Number
1	Sight Plate (L353X1-110)	Nylon	---	5	Bolt (L363X1-110)	Steel	---
2	Sight Plate Gasket (L353X1-110)	Nitrile	---	10	Bowl O-Ring (L363X1-110, L363X1-120)	Nitrile	---
3	Sight Cover (L353X1-110)	Aluminum	---				
4	Metal Bowl (Includes Item 10) (Sight Glass also Includes Items 1, 2, 3 & 5) with Sight (L363X1-110)	Aluminum	104338				
	No Sight (L363X1-120)		104337				

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **ARO** Office or Distributor.

Related Documentation

For additional information refer to:

Safety Information Manual 15301765.

Product Information Manual 15301773.

Maintenance Information Manual 15301781.

Manuals can be downloaded from arozone.com